



PRODUCT MANUAL
FOR DELTAMETHRIN ULV ACCORDING TO IS 15227 : 2002

This Product Manual shall be used as reference material by all Regional/Branch Offices & licensees to ensure coherence of practice and transparency in operation of certification under Scheme-I of Bureau of Indian Standards (Conformity Assessment) Regulations, 2018 for various products. The document may also be used by prospective applicants desirous of obtaining BIS certification licence/certificate.

1.	Product	:	IS 15227 : 2002
	Title	:	Deltamethrin ULV
	No. of Amendments	:	Nil
2.	Sampling Guidelines:		
a)	Raw material	:	Deltamethrin technical used in the formulation of Deltamethrin ULV shall conform to IS 12005.
b)	Grouping guidelines	:	NA (No varieties for the product mentioned in IS)
c)	Sample Size	:	500 ml
3.	List of Test Equipment	:	Please refer ANNEX – A.
4.	Scheme of Inspection and Testing	:	Please refer ANNEX – B.
5.	Possible tests in a day :		
	i) Description ii) Flash Point(Abel) iii) Deltamethrin Content iv) Acidity or alkalinity		
6.	Scope of the Licence :		
	“Licence is granted to use Standard Mark as per IS 15227 : 2002 with the following scope:		
	Name of the product	:	Deltamethrin (1.25 %) ULV

BUREAU OF INDIAN STANDARDS
Manak Bhawan, 9, Bahadur Shah Zafar Marg,
New Delhi – 110002

ANNEX – A
TO PRODUCT MANUAL
FOR DELTAMETHRIN ULV ACCORDING TO IS 15227 : 2002
LIST OF TEST EQUIPMENTS

Major test equipment required to test as per the Indian Standard

Sl. No.	Tests used in with Clause Reference	Test Equipment/Reagents/Chemicals
1.	Flash Point Cl 3.2.2 {IS 1448 (Part 20)}	Cleaning solvent, Coolant, Lubricant, Verification Liquids, Ignitor and pilot light gas, Flash point apparatus/Abel flash point apparatus consisting of test cup, cover assembly, heating vessel, heating device, flash detector, Stirrer, Thermometers 2 (one for the oil cup of range; - 35°C to +70°C, and another for the water bath of the range; -30°C to +80°C), Timing device, Barometer, External cooling bath, Test cup thermal insulating cap, Abel flash point apparatus provided with a stirrer & thermometer, Heating Vessel or bath, Ethylene Glycol
2.	Deltamethrin Content C 1 3.3.1 (Annex A of IS 12005)	<p>HPLC Method :</p> <p>50 ml Volumetric flask, Acetonitrile, G4 Gooch crucible, Liquid Chromatograph, Detector - UV spectrophotometer capable to measure UV absorption at 254 nm, Liquid Chromatographic column, Recorder - One mV full scale recorder Deltamethrin Standard of known purity, Dioxan- UV spectroscopic grade, free of peroxides, Iso-octane- UV spectroscopic grade, 20 Microlitre loop injector, Ultrasonic Bath.</p> <p>Total Bromine Analysis Method-</p> <p>Isopropanol, Metallic Sodium, Formaldehyde, Phenolphthalein solution, Nitric acid, Toluene, Silver Nitrate solution, Amonium thiocyanate solution, Ferric Ammonium sulphate indicator solution, Nitrobenzene, Pipette, Flask, Beaker, Hot plate, Stop watch, Weighing Balance(LC-0.1 mg), Vacuum Pump</p>
3.	Acidity/Alkanity Cl 3.3.2 (Cl 13.5 of IS 6940)	Methyl red indicator solution-aqueous – 1 % (m/v), Bromocresol purple indicator solution, Standard Sodium Hydroxide Solution – 0.5 N, Standard Hydrochloric acid, Acetone, Distilled water, Analytical Balance Range 0 to 200gms LC 0.1mg, Hot plate, Range ambient to 100oC/ Heating mantle/Water bath, Whatman filter paper, Conical Flask, 250ml Capacity, Graduated Cylinder, Range 0 to 100ml LC- 1ml, Test Tube, Litmus paper

The above list is indicative only and may not be treated as exhaustive.

ANNEX – B

SCHEME OF INSPECTION AND TESTING FOR DELTAMETHRIN ULV ACCORDING TO IS 15227 : 2002

1. LABORATORY – A laboratory shall be maintained which shall be suitably equipped (as per the requirement given in column 2 of Table 1) and staffed, where different tests given in the specification shall be carried out in accordance with the methods given in the specification.

1.1 The manufacturer shall prepare a calibration plan for the test equipment.

2. TEST RECORDS – The manufacturer shall maintain test records for the tests carried out to establish conformity.

3. PACKING AND MARKING – The Standard Mark as given in Schedule of the licence shall be stenciled/printed on each container of Deltamethrin ULV or printed on the labels applied to the container, as the case may be, provided always that the material in each container to which this mark is thus applied conforms to every requirement of the specification.

3.1 Packing and Marking shall be done as per clause 4 and 5 of IS 15227. In addition, the following details shall be mentioned on each container legibly and indelibly:

a) BIS Licence No. CM/L_____.

b) BIS website details i.e – “For details of BIS certification please visit www.bis.gov.in”.

4. CONTROL UNIT – For the purpose of this Scheme, the entire quantity of the material mixed in a mixer at a time shall constitute a control unit.

5. LEVELS OF CONTROL – The tests as indicated in column 1 of [Table 1](#) and the levels of control in column 3 of [Table 1](#), shall be carried out on the whole production of the factory which is covered by this plan and appropriate records maintained in accordance with paragraph 2 above.

5.1 All the production which conforms to the Indian Standard and covered by the licence should be marked with Standard Mark.

5.2 On the basis of test results, decision regarding conformity or otherwise of a control unit to the given requirements shall be made as follows:

5.2.1 A sample shall be drawn from each control unit and tested for all the requirements of the specification. If the sample fails in any of the requirement tested, other than Deltamethrin content, the entire control unit represented by the sample shall be considered unfit for the purpose of marking.

5.2.2 In case the sample drawn from the control unit fails in the requirement of Deltamethrin content, but passes in other requirements, the entire quantity of the material in the control unit may be suitably reprocessed and the defect(s) rectified. Such reprocessed material shall be tested again as per Table 1 and the material shall satisfy all the requirements of the specification before it is marked.

6. **RAW MATERIAL** – Deltamethrin technical used in the formulation of Deltamethrin ULV shall conform to IS 12005. A test certificate to that effect shall be obtained from the supplier for each consignment of Deltamethrin technical received. Alternatively, a sample from each consignment shall be tested for its conformity to the Indian Standard mentioned above and a record maintained. However, no testing or test certificate may be required if the material is ISI marked.
7. **REJECTIONS** – Disposal of non-conforming product shall be done in such a way so as to ensure that there is no violation of provisions of BIS Act, 2016.

TABLE 1
LEVELS OF CONTROL

(1)				(2)	(3)		
Test Details				Test equipment requirement R: required (or) S: Sub- contracting permitted	Levels of Control		
Cl.	Requirement	Test Methods Cl. Ref.	Test Method IS		No. of Sample	Frequency	Remarks
3.2.1	Description	3.2.1	IS 15227	R	One	Each Control Unit	See clause 5 of SIT
3.2.2	Flash Point	3.2.2	IS 15227	R	-do-	-do-	
3.3.1	Deltamethrin Content	Annex A	IS 12005	R	-do-	-do-	
3.3.2	Acidity/Alkanity	13.5	IS 6940	R	-do-	-do-	

Note-1: Whether test equipment is required or sub-contracting is permitted in column 2 shall be decided by the Bureau and shall be mandatory. Sub-contracting is permitted to a laboratory recognized by the Bureau or Government laboratories empaneled by the Bureau,

Note-2: Levels of control given in column 3 are only recommendatory in nature. The manufacturer may define the control unit/batch/lot and submit his own levels of control in column 3 with proper justification for approval by BO Head.